



ELITE LETTERBOXES



CENTRIC LETTERBOX INSTALLATION INSTRUCTIONS



Select level site for your letterbox. Cement the base of the 'L-shaped' metal rod into the ground, so it stands upright.

Once cement is dry, place the letterbox over the top of the rod. Ensure the rod goes through the small hole in the plate inside the letterbox. (If you wish to install lighting in the base of your letterbox, do so before placing the letterbox over the rod.)

Secure the letterbox in place by screwing the nut down on the top of the metal rod. This can be accessed through the rear flap.

NOTE: If you have installed lighting under your letterbox and need to replace the light bulb/s simply unscrew the nut from the top of the metal rod, then lift your letterbox up to access the light fitting/s. After the light bulb has been replaced simply follow steps 2 and 3 to re-fit your letterbox.

(Lights and light fittings not included with this product.)

IMPORTANT: This piece is made from quality weathering steel, which exhibits increased resistance to atmospheric corrosion, and forms a rusted finish when exposed to the weather. Please carefully consider the positioning of this product, as staining of surrounding paving/concrete can occur. To seal and minimise any rust marks we recommend the application of Penetrol or a similar product, please note that this may darken the rust colour.